The RUSH EXPERIENCE

B - STAGE

Input/Channel List | All Mics/Cables listed provided by Band

CH	IEM SPLITTER / FOH	Ø	MIC / Cable	AUX Out	
1	Kick – 1 - Condenser	Ø	+48v Audio Technica AE2500	**1**	
2	Kick – 1 - Dynamic	Ø	Audio Technica AE2500	**2**	Click
3	Kick – 2 - Condenser	Ø	+48v Audio Technica AE2500	**3**	Slate Click
4	Kick – 2 - Dynamic	Ø	Audio Technica AE2500	**4**	S – GTR
5	Snare - Top		Audio Technica ATM25	**5**	STPB
6	Snare - Bottom	Ø	+48v Audio Technica AE3000	**6**	STPB
7	Hi-Hat		+48v Audio Technica ATM450	**7**	USB L
8	Timbale		+48v Shure Beta 98	**8**	USB R
9	Concert Tom 1 & 2 – **Y (6"/8")**	Ø	+48v Audio Technica AE3000		
10	Concert Tom 3 & 4 – **Y (10" & 12")**	Ø	+48v Audio Technica AE3000		
11	Rack 1 - (12")		+48v Audio Technica AE3000	**BUSS OUT**	**In-Ears**
12	Rack 2 – (13")		+48v Audio Technica AE3000	**1**	Vince - 1
13	Rack 3 – (15")		+48v Audio Technica AE3000	**2**	Vince - 1
14	Floor Tom – (18")		+48v Audio Technica AE3000	**3**	Dave - 2
15	Gong Bass Drum - (20")		Shure Beta 52A	**4**	Dave - 2
16	Ride Cymbal	Ø	+48v Audio Technica AT2021	**5**	Burke - 3
17	Over Head SR		+48v Audio Technica AT4040	**6**	Burke - 3
18	Tubular Bells & Bell Tree - **Y**	Ø	+48v Audio Technica AE3000	**7**	
19	Over Head SL		+48v Audio Technica AT4040	**8**	
20	Cowbells		+48v Audio Technica AT2020		
21	E Kit		XLR		
22	Bass		XLR		
23	Guitar L		XLR		
24	Guitar R		XLR		
25	Acoustic		XLR		
26	MIDI Foot Pedals Burke		XLR		
27	Keys L		XLR		
28	Keys R		XLR		
29	MIDI Foot Pedals Dave		XLR		
30	Burke Vox		Shure Beta 57		
31	Dave Vox Center	Ø	Audio Technica AE6100		
32	Dave Vox Keys		Audio Technica AE6100		
33	Tracks L				
34	Tracks R				
35					
36					
37					
38					

Live it All Again